

# Installation Guide - Ball Catch

EMTEK®

Door Prep	Install Strike Plate	Install Ball Catch
<p>7/8" DIA. EDGE BORE 1-1/2" DEEP</p> <p>1"    1 33/64"    2 1/8"</p> <p>1/16" DEEP</p>	<p>Install Strike Plate</p>	<p>Install Ball Catch</p>
<p>Door Jamb Prep</p> <p>3/16" DEEP RELIEF</p> <p>1"    1 33/64"    2 1/8"</p> <p>1/16" DEEP</p>		

# Installation Instructions - Roller Catch

EMTEK®

Door Prep	Install Strike Plate	Install Roller Catch
<p>1 5/8" DEEP</p> <p>1"    3 3/8"    2 5/16"    2 7/8"</p> <p>1/4" DEEP</p>	<p>Install Strike Plate</p>	<p>Install Roller Catch</p>
<p>Door Jamb Prep</p> <p>1 1/2"    2 1/4"    1 1/16"</p> <p>5/32" DEEP</p>		